

**Kod części: 481010395258** ; artykuł pasuje do poniższych urządzeń

technical12nc	Model	Marka
857464601001	EKI 7640/IN	BAUKNECHT
857670129020	ACM 701 NE/01	WHIRLPOOL
857672029000	ACM 720/NE	WHIRLPOOL
857673029000	ACM 730/IX	WHIRLPOOL
857677501000	ACM 775/NE	WHIRLPOOL
857677701020	ACM 777/BA	WHIRLPOOL
857670201004	ACM 702/NE	WHIRLPOOL
857937401005	301.476.18 HB I4 HOB IK	IKEA
857463801020	ETI 6740 IN/1	BAUKNECHT
857463801030	ETI 6740 NE/1	BAUKNECHT
857464001010	ETI 6730/1	BAUKNECHT
857670101024	ACM 701/BA	WHIRLPOOL
857670229001	ACM 702/NE	WHIRLPOOL
857670801001	ACM 708/NE	WHIRLPOOL
857660229001	ACM 602/NE	WHIRLPOOL
857670141020	ACM 701/BA	WHIRLPOOL
857670001005	ACM 700/NE	WHIRLPOOL
857670029001	ACM 700/NE	WHIRLPOOL
857670101004	ACM 701/IX	WHIRLPOOL
857670101014	ACM 701/NE	WHIRLPOOL
857670129001	ACM 701/IX	WHIRLPOOL
857670129011	ACM 701/NE	WHIRLPOOL
857937501004	201.476.47 HB I73 HOB IK	IKEA
857670701004	ACM 707/NE	WHIRLPOOL
857670901001	ACM 709/BA	WHIRLPOOL
859412301001	PCTOC240060F	PRIVILEG
857660429001	ACM 604/NE	WHIRLPOOL
857662129001	ACM 621/LX	WHIRLPOOL
857670129021	ACM 701 NE/01	WHIRLPOOL
857672029001	ACM 720/NE	WHIRLPOOL
857932915000	CLHB 30 NE	COOKE&LEWIS
857672029010	ACM NY	WHIRLPOOL
857676518010	ACM 765/NY	WHIRLPOOL
857677701030	ACM 777/LX	WHIRLPOOL
857660029001	ACM 600/NE	WHIRLPOOL
857673029001	ACM 730/IX	WHIRLPOOL
857670601004	ACM 706/NE	WHIRLPOOL
857933515000	CLHB 31 NE	COOKE&LEWIS
857197201005	AKM 972/BA	WHIRLPOOL
857463901011	EKI 6640/IN/01	BAUKNECHT
857670401001	ACM 704/NE	WHIRLPOOL
857934401001	PIT 403/NE	LADEN

**Kod części: 481010395258** ; artykuł pasuje do poniższych urządzeń

---

857463801021	ETI 6740 IN/1	BAUKNECHT
857670118001	ACM 701/BA/02	WHIRLPOOL
857670118021	ACM 701/IX/02	WHIRLPOOL
857676518001	ACM 765/BA	WHIRLPOOL
857677418001	ACM 774/BH	WHIRLPOOL
857672201001	ACM 722/NE	WHIRLPOOL
857677501001	ACM 775/NE	WHIRLPOOL
857677701000	ACM 777/NE	WHIRLPOOL
857677701021	ACM 777/BA	WHIRLPOOL
857934501001	PIT 404/NE	LADEN
857496401011	EKI 9640/IN	BAUKNECHT
857670701024	ACM 707/BA	WHIRLPOOL
857464001011	ETI 6730/1	BAUKNECHT
857670501004	ACM 705/NE	WHIRLPOOL
857670701014	ACM 707/IX	WHIRLPOOL
857670755000	ACM707NE	WHIRLPOOL
857936801004	AKS 368/NE	IGNIS
857463801031	ETI 6740 NE/1	BAUKNECHT
857936901001	AKS 369/NE	IGNIS
855783001000	402.228.29 HB 18 HOB IK	IKEA
855780001000	ACM 800/NE	WHIRLPOOL
855780201000	ACM 802/NE	WHIRLPOOL
855785501000	ACM 755/NE	WHIRLPOOL
855785601000	ACM 756/NE	WHIRLPOOL
855788001000	ACM 904/NE	WHIRLPOOL
855788801000	ACM 608/NE	WHIRLPOOL
855788901000	ACM 609/NE	WHIRLPOOL
855780801000	ACM 808/NE	WHIRLPOOL
855780801010	ACM 808/BA	WHIRLPOOL
855780801020	ACM 808/BA/S	WHIRLPOOL
855781201000	ACM 812/BA	WHIRLPOOL
855783301000	PIT 002/NE	LADEN
855789101000	ACM 911/BF	WHIRLPOOL
855789101010	ACM 911/BF/S	WHIRLPOOL
855789201000	ACM 912/BF	WHIRLPOOL
857937453000	202.259.23	IKEA
855780501000	ACM 805/NE	WHIRLPOOL
855780501010	ACM 875/BA	WHIRLPOOL
855783201000	PIT 405/NE	LADEN
855783401000	PIT FLOWER	LADEN
855783501000	PIT 001/NE	LADEN
855780901000	ACM 809/NE	WHIRLPOOL
855780901010	ACM 809/BA	WHIRLPOOL

**Kod części: 481010395258** ; artykuł pasuje do poniższych urządzeń

---

855780901020	ACM 809/BF	WHIRLPOOL
855783601000	AKS 368/NE	IGNIS
855783701000	AKS 369/NE	IGNIS
855780701000	ACM 807/BF	WHIRLPOOL
855780701010	ACM 807/BF/S	WHIRLPOOL
855780701020	ACM 807/BA	WHIRLPOOL
855781601000	ACM 816/BA	WHIRLPOOL
855781001000	ACM 810/BF	WHIRLPOOL
855781001020	ACM 810/LX	WHIRLPOOL
855780201010	ACM 802/BA	WHIRLPOOL
855782201000	ACM 822/NE	WHIRLPOOL
855784001000	CLHB 30/NE	COOKE&LEWIS
855784101000	CLHB 31/NE	COOKE&LEWIS
857467401000	ETI 6740/2 IN	BAUKNECHT
855781653000	ACM816BA	WHIRLPOOL
855782001000	ACM 820/BA	WHIRLPOOL
857463801120	ESIO 6740 IN	BAUKNECHT
857463801130	ESIO 6740 NE	BAUKNECHT
855781301000	ACM 913/BA	WHIRLPOOL
857463701120	ESIO 6640 IN	BAUKNECHT
857463701130	ESIO 6640 NE	BAUKNECHT
855780201001	ACM 802/NE	WHIRLPOOL
855781401030	ACM 814/LX	WHIRLPOOL
855781301010	ACM 813/LX	WHIRLPOOL
855784901030	ACM 849/BF	WHIRLPOOL
857468101110	ESMIF 8740 NE	BAUKNECHT
857468201100	ESMIF 8740 IN	BAUKNECHT
855784901041	ACM 849/LX	WHIRLPOOL
855781201011	ACM 812/NE	WHIRLPOOL
855781201041	ACM 812 LX	WHIRLPOOL
857466601001	ETI 1740 IN	BAUKNECHT
855781701000	ACM 817/NE	WHIRLPOOL
855782801020	ACM 828/LX	WHIRLPOOL
855783001001	402.228.29 HB 18 HOB IK	IKEA
855782801030	ACM 828/BA	WHIRLPOOL
855779601000	ACM 796/NE	WHIRLPOOL
855782401000	ACM 8512 BA	WHIRLPOOL
855784901050	ACM 849/01/BA	WHIRLPOOL
855778801000	ACM 788 NE	WHIRLPOOL
855779001000	ACM 790/NE	WHIRLPOOL
855779801000	ACM 798/NE	WHIRLPOOL
857650901000	ACM 509/NE	WHIRLPOOL
857655501000	ACM 555/NE	WHIRLPOOL

**Kod części: 481010395258** ; artykuł pasuje do poniższych urządzeń

---

855789101020	ACM 911/BF/04	WHIRLPOOL
855789201020	ACM 912/BF/04	WHIRLPOOL
855781201001	ACM 812/BA	WHIRLPOOL
857465901000	EKIF 6640 IN	BAUKNECHT
855780701001	ACM 807/BF	WHIRLPOOL
855780701011	ACM 807/BF/S	WHIRLPOOL
855781001001	ACM 810/BF	WHIRLPOOL
857465301000	ESIFF 6640 IN	BAUKNECHT
857465301020	ESIFF 6640 NE	BAUKNECHT
855780801030	ACM 808/BA/WH	WHIRLPOOL
855784901011	ACM 849/BA	WHIRLPOOL
855784901021	ACM 849/BA/S	WHIRLPOOL
855782853020	ACM828BA	WHIRLPOOL
855780701021	ACM 807/BA	WHIRLPOOL
857976061000	IHI 760 FX	CYLINDA
857919001000	SIM562B	SMEG
855776001000	ACM 760/BA/N	WHIRLPOOL
855781661000	ACM 816/BA/N	WHIRLPOOL
855785861000	ACM 858/BA/N	WHIRLPOOL
857919601000	SIM581B	SMEG